


How to use the suction unit

Step1: install the arm and hood




Tight each screw after installation

Watch each part's turns



Step2: Conect with the power supplying



Step3 : Adjust to suitable gear position (from low to high)



Step4 : Move the suction hood to right direction



Last Step : start working

